



KL-1340-201

Support Joint Socket Spanner (41mm)



Product information EN
⚠ Read and understand before use!



www.gedore-automotive.com



GEDORE Automotive GmbH

Breslauer Straße 41
78166 - Donaueschingen
Postfach 1329
78154 Donaueschingen - GERMANY

☎ +49 (0) 771 / 8 32 23-0
☎ +49 (0) 771 / 8 32 23-90
✉ info.gam@gedore.com
🌐 gedore-automotive.com

GEDORE TOOLS, INC.

Only for USA, Canada & Mexico / Sólo para EE.UU., Canadá y México
Seulement pour les USA, le Canada et le Mexique
7187 Bryhawke Circle, Suite 700
North Charleston, SC 29418, USA

☎ +1-843 / 225 50 15
☎ +1-843 / 225 50 20
✉ info@gedoretools.com
🌐 gedore.com

Version 2- 07/2021

Product description

KL-1340-201 - Support joint socket spanner (41 mm)

Suitable for BMW, ALPINA, Peugeot and Citroën. Particularly suitable for, for example, BMW series 5 (F07, F10, F11), series 6 (F06, F12, F13), series 7 (F01, F02, F03, F04); ALPINA B6 (F06); Peugeot 307, 308, 3008, 5008, Partner, RCZ; Citroën Berlingo, C4, and many more.

To properly loosen and tighten screwed support joints with a spanner size of 41 mm.

1/2"



Scope of supply/component overview

Part no.	Description	Qty.
KL-1340-201	Support joint socket spanner (41 mm)	1

Specifications

Size:.....41mm
 Drive:..... 1/2"
 Length:75mm
 Weight:700g
 Profile:..... 12-edge

⚠ Safety instructions and regulations

- ✔ **Before using** the tool, read and understand all safety instructions and **follow** them for **safe use**!
- ✔ Ensure that maintenance and repair work on motor vehicles is only carried out by trained specialists in specialist automotive workshops, taking into account occupational safety and accident prevention as well as the instructions of the vehicle manufacturer!
- ✔ **Prior to each use**, check the tool **carefully** for damage, loose parts or unauthorised modifications. **Never** use it if you notice any such deficiencies!
- ✔ Use the tool **as intended** and **always** observe the vehicle-specific application procedures in the vehicle manufacturer's repair manual!
- ✔ **Always** wear your personal protective equipment (for example safety goggles, protective gloves, safety shoes) when working!