



KL-4051-310

Screwdriver Bit Socket, Polydrive M10



Product information EN
⚠ Read and understand before use!

www.gedore-automotive.com



GEDORE Automotive GmbH

Breslauer Straße 41
78166 - Donaueschingen
Postfach 1329
78154 Donaueschingen - GERMANY

☎ +49 (0) 771 / 8 32 23-0
☎ +49 (0) 771 / 8 32 23-90
✉ info.gam@gedore.com
🌐 gedore-automotive.com

GEDORE TOOLS, INC.

Only for USA, Canada & Mexico / Sólo para EE.UU., Canadá y México
Seulement pour les USA, le Canada et le Mexique
7187 Bryhawke Circle, Suite 700
North Charleston, SC 29418, USA

☎ +1-843 / 225 50 15
☎ +1-843 / 225 50 20
✉ info@gedoretools.com
🌐 gedore.com

Version 08/2023

4051-310_EN230312.indd

Product description

KL-4051-310 - Screwdriver bit socket, 1/2", Polydrive, M10

For loosening and tightening Polydrive M10 screw connections.

Ideal to remove and tighten cylinder head retaining bolts and the screw connection of the camshaft timer on VW-Audi engines.

Scope of delivery/single part overview

Pos.	Part no.	Description	Qty
A	KL-4051-3310	Screwdriver bit socket Polydrive M10, 140mm	1
B	KL-4051-3010	Screwdriver bit socket Polydrive M10, 55mm	1

Specifications

Drive:..... 1/2"

Size (waf):..... M10

Profile:..... RIBE® (Polydrive)

Length: 55 + 140mm



⚠ Safety instructions and regulations!

- ✔ **Before using** the special tool, read and understand **all** warning and safety instructions and **follow** them for **safe use!**
- ✔ Work on electrical installations may **only** be carried out by appropriately **qualified personnel!**
- ✔ **Always** observe and adhere to **all** safety rules and regulations when working on electrical installations!
- ✔ Use the special tool **as intended**, and **always** carry out maintenance and repair work in compliance with the regulations on occupational safety and accident prevention as well as the vehicle manufacturer's instructions!
- ✔ **Before each use**, check the special tool **carefully** for damage, loose parts, or unauthorised modifications. **Never** use it if you notice any such deficiencies!
- ✔ **Always** wear your personal protective equipment (*such as safety goggles, protective gloves, safety shoes*) during work!