



Start/stop set CordlessControl, type F (remote-controlled socket, transmitter, 3 x multi tape)

- When starting up/shutting down the cordless tool, the connected mains-powered vacuum cleaner starts/stops automatically
- Compatible with standard cordless, mains-powered tools and vacuum cleaners available on the market
- Manual starting of the vacuum cleaner is also possible with the remote button at the coupling bush of the hose
- "Vibration detection" function at the transmitter permits automatic start-up/shut-down of the vacuum cleaner by detecting vibrations
- If the vibrations are too low, the transmitter can be connected directly to the extracting tool using the multi tape
- Multi tape to fix the transmitter to all standard hose diameters
- Start/stop cordless control replaces the function of the integrated power socket for a mains-powered tool

Order no.	630231000
EAN code	4061792192645

Radio frequency	2402 - 2445 Mhz
Mains voltage	220 - 240 V
Power supply transmitter	CR2032
Signal strength	- 6 dBm