## BOSCH

Battery starter set ProCore, 4.0 Ah, Battery type, battery voltage: C18V



#### Order data

Order number	073863 C18
GTIN	3165140970341
Item class	03B

## Description

Version: ProCore battery starter set Professional - suitable for all Bosch cordless devices in the 18 Volt class.

#### Supplied with:

Supplied with charger and 2 battery packs.

# **Technical description**

Type of rechargeable battery	Lithium-ion
Manufacturer's designation	ProCORE18V 4.0Ah
Number of rechargeable batteries contained	2
Battery capacity	4 Ah
suitable for	Bosch 18 V
Battery voltage	18 V
Weight per battery	515 g
Charging time per battery	48 - 65 min
Product name attribute	4.0 Ah
Type of product	Battery incl. charger