BOSCH

Auto-start system WirelessGCT30-42



Order data

| Order number | 070237 GCT30-42 |
|--------------|-----------------|
| GTIN | 4053423240023 |
| Item class | 03B |

Description

Version:

The auto-start system can be used for all cordless tools with an extraction function. Thanks to the wireless automatic on/off system, the vacuum cleaner is switched on and off automatically (vibration sensor) or via the remote control button (manually) on the cordless tool. This saves valuable time. Easy to mount on the tools thanks to flexible rubber straps.

System status can be read off easily thanks to bright coloured LEDs.

Supplied with:

1 pc. GCT 30-42, 3 pcs. flexible rubber straps

Technical description

| Type of switch | manual |
|-------------------------------|---------------------|
| Type of switch | Vibration detection |
| Battery designation | CR2032 |
| Status display | LED |
| Number of batteries contained | 1 |

| IP Index of Protection | IP 54 |
|------------------------|-----------------|
| Height | 42 mm |
| Battery type | Button cell |
| Weight | 0.3 kg |
| Width | 18 mm |
| Power supply | Battery-powered |
| Length | 43 mm |
| Packaging | cardboard |