
THE SAFER WAY TO CUT.



TECHNICAL DATA SHEET

SECUNORM MIZAR NO. 1250019

Safety technology



Automatic blade retraction – a high degree of safety

The SECUNORM MIZAR is equipped with automatic blade retraction: as soon as you release the lever, the blade disappears into the handle – and it stays there too. This provides a high degree of safety from cut injuries.



SQUEEZE-LEVER KNIFE WITH AUTOMATIC BLADE RETRACTION FOR ALL NORMAL CUTTING JOBS.

Order No. 1250019.17

More leverage, more performance. With ceramic blade.

The slimline SECUNORM MIZAR is your gateway into our world of quality squeeze-grip knives. Instead of a slider, a lever is responsible for releasing the blade, and instead of a steel blade, it has a permanently sharp ceramic blade. It is particularly versatile and efficient and can be used for all common cutting materials and for a wide variety of cutting types – thanks to its perfect handling.

Ergonomically shaped

Right-handed? Left-handed? It makes no difference with the SECUNORM MIZAR. Its ergonomically designed, lockable squeeze grip comfortably fits all hands. Making cutting super easy. Regardless of the number of cuts you make per day.

Plastic with a content

A glass fibre content, to be precise. These fibres are what make the SECUNORM MIZAR super strong and super solid. The durability of this safety knife is remarkable.

Easy blade change


No tools are needed to change the blade. Two hands can do the job. Move the 3-in-1 safety lock to position "blade change". Swing out the lever, flip the blade cover, replace the blade. Close the cover, store the lever, continue cutting!


Multipurpose locking function


The SECUNORM MIZAR 3-in-1 safety lock is unique. Slide it to lock and unlock your cutting tool. And when necessary, move it to position 3 to safely change or rotate the blade.

2-cutting edge blade

Before you need to change the quality blade, you have the chance to turn it over once. Usage time of the blade is doubled and fatigue is held at bay: with a simple flip of the blade, your product will cut like new.







PRODUCT FEATURES

Technical features



High safety



Tool-less blade change



Abrasion resistant



Very ergonomic



Safety lock



2-cutting edge blade



Cutting depth



Ceramic



Rounded-tip trapezoid blade



For right and left handers



Lanyard hole



Printable for promotional purposes

Main cutting materials



Cardboard: up to 2-ply



Wrapping, stretch and shrink foil



Plastic strapping band



Tape



Bagged goods



Layers of foil or paper



Yarn, cord



Textile, material

Installed blade



NO. 65232C

0.65 mm, ceramic, rounded blade tips, deep-edged







0.63 mm, rounded blade tips, deep-edged



NO. 5233

0.63 mm, 1-sided ground-edge



NO. 8852

NO. 56 0.63 mm

cover.

0.63 mm, TiN-coated





TiN-coated



NO. 5232

0.63 mm, deep-edged



NO. 610

0.63 mm, stainless



0.63 mm, stainless,



NO. 52

0.63 mm



NO. 85232

0.63 mm, deep-edged, TiN-coated




NO. 85233

TiN-coated

0.63 mm, 1-sided ground-edge,

BLADE CHANGE

rearmost position.



Move the 3-in-1 activator into its

Swing the lever completely **out of**

the handle and flip open the blade



Now you can either rotate or replace the blade. Re-close the blade cover.



Swing the lever back into the handle and set the 3-in-1 activator to either lock or unlock.



Safety poster



Technical data sheet



Consulting service

PRODUCT AND PACKAGING DETAILS

Order No.	NO. 1250019.17	Packaging unit	1 in single unit box
Knife size (L x W x H)	139 x 15.6 x 50.5 mm	Size Single unit box	143 x 19 x 55 mm
Weight knife	58.0 g	Weight single unit box	72.5 g
Basic material	Glass fibre reinforced plastic	EAN Code single unit box	4002632802713
Cutting depth	13 mm	Quantity in outer pack	10 knives
		Size outer pack	114 x 104 x 148 mm
		Weight outer pack	777.0 g
		EAN Code outer pack	4002632852718
		Customs tariff number	69149000

SAFETY CERTIFICATE

Date of issue	07.04.2020	Certificates and awards
Certification	GS certificate NO. 179274-7111-55094-2020	VPA
	NO. 173274-7111-33034-2020	Sports Statement

SAFETY ADVICE

To ensure that you use your new MARTOR knife safely and most effectively, please read and note the following user-instructions. Please keep the written guide in a safe place so that you can access it at any time.

- **1. General application instructions:** Please always use the product carefully for manual cutting work only and not for any purposes other than those that are intended. Please take the correct handling and the proper use of the knives into account in this regard. As an additional safety measure, we recommend the wearing of safe gloves.
- 2. Special application instructions to avoid the danger of injuries: Only use knives that are in perfect condition and have sharp, clean and undamaged MARTOR blades. Employ the utmost care when handling the knives. Prior to use, familiarise yourself with the safety features and their functioning. Ensure that these safety features are not impaired by the type of material to be cut. CAUTION: The blade is sharp and can result in serious and deep cuts. Therefore, never reach into the blade! Do not place your free hand in the line of cutting and never cut directly towards you.
- **3. Replacement of spare parts:** Replace any blades that become dull at the right time! Use only the replacement blades from MARTOR for this purpose. Dispose of old blades in a

proper fashion. They should not be placed in a waste paper bin, as this poses a considerable danger of injuries. Never perform any repairs yourself. If the knife shows signs of aging or any other wear, e.g. which impair safety features, blade changing or usage, the knife must be taken out of service and replaced. Do not modify this product in any way. Modifications of any kind may impair product safety. CAUTION: The risk of injury caused by manipulation of this product is extremely high.

- **4. Non-use of the knife:** Always secure the blade in such a way (depending on product type) that injuries due to cuts are excluded. Store the knife in a secure place.
- **5. Care instructions:** To guarantee a long service life, always keep the knife clean and do not expose it to unnecessary soiling and humidity.

CAUTION: No liability will be assumed for consequential losses. Subject to technical changes and errors! This knife does not belong in the hands of children!

BELT HOLSTER M WITH CLIP NO. 9921



USED BLADE CONTAINER NO. 9810



WALL MOUNT BRACKET USED BLADE CONTAINER NO. 9845



Include it in your order now! With this mounting bracket you can fix your USED BLADE CONTAINER to a central location.

Use the clamp and screws and nuts supplied with the product to attach it to either a pipe or a rod.

What do you do with your cutting tools when you are not ac-

tually using them? The MARTOR BELT HOLSTER M is a robust

holder that allows you to carry all midsize MARTOR knives as well as our safety scissors at all times. In addition, the interior and exterior pockets are designed to allow you to load different tools: for example you can carry an extra safety knife, a pen and a pack of blades. The MARTOR BELT HOLSTER is the ideal place to stow your tools safely when moving from A to B - and have them at hand, as soon as they are required.

You can fill the USED BLADE CONTAINER with the content of

your SAFEBOX. Or directly with your used blades. When the

box is full, turn the lid until it shuts. Now the box cannot be reopened. The next step is to safely and completely dispose of the filled USED BLADE CONTAINER as normal waste.

SAFEBOX NO. 108000



The SAFEBOX is large enough to store a large number of used blades safely. And at the same time, it is compact

enough to carry with you. The two slits are not only used for filling, but also to "shorten" your snap-off blades. When your SAFEBOX is full, empty it into your USED BLADE CONTAINER.

MANUFACTURER

MARTOR KG | Lindgesfeld 28 | 42653 Solingen | Germany T +49 212 73870-0 | info@martor.de | www.martor.com