



## KL-0132-14 K

### Thread Repair Kit for Exhaust Sensor



**Product information** EN  
⚠ Read and understand before use!



[www.gedore-automotive.com](http://www.gedore-automotive.com)



#### GEDORE Automotive GmbH

Breslauer Straße 41  
78166 - Donaueschingen  
Postfach 1329  
78154 Donaueschingen - GERMANY

☎ +49 (0) 771 / 8 32 23-0  
☎ +49 (0) 771 / 8 32 23-90  
✉ info.gam@gedore.com  
🌐 gedore-automotive.com

#### GEDORE TOOLS, INC.

Only for USA, Canada & Mexico / Sólo para EE.UU., Canadá y México  
Seulement pour les USA, le Canada et le Mexique  
7187 Bryhawke Circle, Suite 700  
North Charleston, SC 29418, USA

☎ +1-843 / 225 50 15  
☎ +1-843 / 225 50 20  
✉ info@gedoretools.com  
🌐 gedore.com

Version 10/2022

0132-14K\_EN220908.indd

## Product description

### KL-0132-14 K - Thread repair kit for exhaust sensor

Universal fit for passenger cars, commercial vehicles and vans, especially for NOx sensors, lambda sensors, and injection units for soot/particle filter regeneration with mounting threads M20x1.5 and M22x1.5.

For quick recutting of coked or damaged M20x1.5 and M22x1.5 mounting threads on the exhaust pipe. The extremely short taps and the special ring ratchet spanner with joint make it easy to work even in very confined spaces. This saves time-consuming removal of the entire exhaust pipe. The open double ring spanner included in the kit allows easy loosening and tightening of the exhaust sensors and units.

EN



### Scope of delivery/Spare parts overview

Item	Part no.	Description	Qty.
-	KL-0132-14 K	<b>Thread repair kit for exhaust sensor</b>	<b>1</b>
1	400 22x24	Open double ring spanner	1
2	1720.0130	Ring ratchet spanner SW13 with joint	1
3	KL-0132-1411	Tap M20x1.5 with SW13	1
4	KL-0132-1412	Tap M22x1.5 with SW13	1
-	KL-0132-1490	Foam insert	1

**i Storage system: Plastic case - KL-4990-9224**

### Specifications

Taps: .....M20x1.5 + M22x1.5  
 Tap length: ..... 45mm  
 Tap drive: ..... SW13mm  
 Double ring spanner: ..... SW22 + 24 (open)

### ! Safety instructions and regulations

- Before using the special tool, read and understand **all** safety instructions and **follow** them for **safe use!**
- Use the special tool **as intended** and **always** carry out maintenance and repairs in compliance with the regulations on occupational safety and accident prevention as well as the vehicle manufacturer's instructions!
- Before each use, check the special tool **carefully** for damage, loose parts, or unauthorised modifications. **Never** use it if you notice any such deficiencies!
- Always** wear your personal protective equipment (such as safety goggles, protective gloves, safety shoes) during work!